



No.	Parts Description
1	FRONT PANEL
2	CHASSIS BASE
3	TOP COVER
4	SIDE COVER (L)
5	SIDE COVER (R)
6	EMI I/O SHIELD
7	CARD GUIDE/FAN HOLDER
8	H.D.D FRAME
9	FOOT STAND
10	CD-R MOUNTING BRACKET
11	3.5" MOUNTING BRACKET-B
12	SWITCH/LED ASSY
13	I/O PANEL
14	KEY FLAP
15	#6*32 4.5 SCREW
16	GROUND COPPER SCREW
17	#6*32 HEX SCREW
18	BUZZER
19	INTRUSION SWITCH(OPTION)
20	SIDE PANEL CLIP
21	VENT COVER
22	UPPER AIR DUCT(OPTION)
23	LOWER AIR DUCT(OPTION)
24	SIDE USB(OPTION)

IW-S508G-ATX

PARCEL LIST

Diagram	Parts Description	QTY	Diagram	Parts Description	QTY	Diagram	Parts Description	QTY	Diagram	Parts Description	QTY	Diagram	Parts Description	QTY
	CD-R MOUNTING BRACKET	4		GROUND COPPER SCREW	1		RUBBER FOOT	4		I/O PANEL	6		KEY FLAP	1
	3.5" MOUNTING BRACKET-B	4		#6*32 HEX SCREW	16		#6*32 4.5 SCREW	9		M3*5 SCREW	6			

PARCEL LIST For IW-S508 Intel P4 CPU (OPTION)

Diagram	Parts Description	QTY	Diagram	Parts Description	QTY
	GROUND STANDOFF	4		RUBBER BUMPER	1
	#6*32 8 SCREW	4			