

Circuit Specialists

www.circuitspecialists.com

www.circuitspecialists.eu

3 in 1 Program-Controlled Rework Station

INSTRUCTION MANUAL

CSI853B+

English



Thank you for purchasing this program-controlled rework station, this product is specially designed for lead free desoldering. Please read the instructions carefully before use. And after reading, please keep for future reference

Safety Regulations

To use this product, the following basic measures should be strictly followed to avoid hazards of electric shock, bodily injury, fire and other phenomenon.

1. In order to ensure safety, please turn off the power switch when not in use. When not in use for an extended period, please unplug the power cord!!!
2. Serious consequences may result if non-original or non-approved parts are used.
3. Machine failure must be maintained by professional or our designated personal.
4. This product uses three wire grounding plug must be inserted into three grounding socket, do not change the plug or no use the three floating head adapter bad grounding.
5. After the rework station is switched on, its temperature can exceed 400 degrees centigrade. Do not use near flammable or explosive objects. To avoid burns, do not touch the metal part of the soldering iron.
6. Do not leave the work area when the rework station is switched on.
7. The power cord must be unplugged and the rework station Must be allowed to cool before installing or replacing parts.
8. After used, remember that cooling the unit before installation.
9. Soldering produces fumes, ensure there is adequate ventilation.
10. Please keep the air outlet clear and unobstructed.

Warning

1. If the power cord is damaged, it must be replaced by a manufacturer or a maintenance specialist to avoid danger.
2. The tool must be placed on its support when not in use.
3. Be careful when using this device in the vicinity of flammable materials; Never use this device for extended periods in the same location.
4. Be aware that heat may be transferred to distant flammable materials; Someone must be present at all times while the device is connected.
5. This device is not intended to be operated by individuals with diminished physical, sensory, or mental capacities or by those who lack experience (such as children), except in the presence of individuals qualified to provide necessary supervision and guidance;

